

Issued: 10/89

Revised: 04/12/07

**W A T E R O U S**

WATEROUS COMPANY

SOUTH ST. PAUL, MINNESOTA

SERVICE PARTS LIST

## PRIMING VALVE ASSEMBLY


REF NO.	DESCRIPTION	REF NO.	DESCRIPTION
Q7	Cover plate, manual priming valve. (Included with Q18, may be ordered separately.)	Q21	Priming valve solenoid
Q8	Priming valve spring	Q23	Groove pin SS, 1/8 x 7/8 in.
Q9	Switch cover, electric manual priming valve	Q24	O-ring packing
Q10	End cap, priming valve	Q25	Lock washer, 1/4 in.
Q11	Priming valve plunger	Q26	Snap ring
Q12	Plunger rod	Q27	(Refer to Q23)
Q13	Plunger insert	Q29	Rd hd screw, SS, No. 10-32 x 3/8 in.
Q14	Switch operating spring	Q30	Rd hd screw, 1/4-20 x 5/8 in.
Q15	Spring housing	Q46	Actuating arm
Q17	Priming valve body	Q47	Actuating arm socket
Q18	Push button switch assembly, (Includes Q7)	Q48	Repair Kit consists of (Q13, Q20, Q23, Q24, Q26, Q27, Q29, Q46, and Q47)
Q19	Switch cover grommet	Q72	Screw, hex hd, 1/4-20 x 5/8 in.
Q20	Quad ring	Q73	Cable tie

## PLEASE NOTE

**WHEN ORDERING PARTS PLEASE SUPPLY PUMP SERIAL NUMBER**

SPL8683

Page 1 of 2



REPAIR  
KIT \* COMPONENTS OF REPAIR KIT Q48

Q48